




NON-CAUSTIC OVEN CLEANER POWDER

EASY TO USE!



Directions

1. Fill bottle with 32oz of warm water.
2. Carefully pour in one (1) packet of powder.
3. Replace foaming trigger and shake vigorously for a few seconds. Wait 3 minutes.
4. Spray and let soak for 5 mins. Rinse with clean water after use. Repeat if necessary.

Safer to use than caustic degreasers ✓

Works incredibly well to remove soils and baked on carbon ✓

Versatile uses for multiple surfaces ✓

Smaller packaging footprint for tight spaces ✓

Will help environmental social governance ratings ✓



Sustainable




1 case saves
16 bottles
from Landfills



Magnus
16005 gateway drive
Suite 300
Frisco, TX 75033
855.962.4687
magnusclean.com

To Reorder



20850037836141